

FML EXPERTISE

VIVA®

Selected by the *Institut Français de la Vigne et du Vin* (IFV).
O. oeni strain fast and resistant to difficult conditions.

FML EXPERTISE VIVA® brings fruitiness and freshness to white, rose and red wines.

FML EXPERTISE VIVA® is a great complement for the FML EXPERTISE® range. It is a highly tolerant strain, which can rapidly perform the malolactic fermentation under difficult conditions (low pH, high alcohol, low temperatures). FML EXPERTISE VIVA® is also a very easy-to-use product as it can be used for direct inoculation without rehydration.




FML EXPERTISE VIVA® is produced following the specific MBR® process, which enhances its resistance to wine conditions when used for direct inoculation, or after a short rehydration phase, and makes it remarkably stable during storage.

The bacterial strain of FML EXPERTISE VIVA® has been chosen for its fermentative and organoleptic qualities during a selection program for white, red, and rosé wines lead by the IFV institute. In addition to a very good malolactic activity, FML EXPERTISE VIVA® has a very low production of volatile acidity associated to a low consumption of the citric acid, and brings a fruity and complexity aromatic to the wine.

❧MICROBIOLOGICAL AND ENOLOGICAL PROPERTIES❧

- Fast implantation following direct inoculation.
- Very fast malolactic fermentation.
- Resistant to alcohol content up to 16% vol., and even 17% vol. if there is no other limiting factor.
- Resistant to pH levels ≥ 3.1 .
- Resistant to up to 60 mg/L of total SO₂ and 10 mg/L of free SO₂. It is important to pay attention to the SO₂ addition before the inoculation of bacterias. In case of low pH, molecular SO₂ is in bigger quantity and has a strong inhibiting effect on bacterias.
- Resistant to temperatures $> 15^{\circ}\text{C}$.
- Suitable for the three different inoculation times: co-inoculation, early inoculation, and sequential inoculation.
- Low production of volatile acid, which is especially interesting for a use in co-inoculation.
- "Phenol negative" bacteria, which means that FML EXPERTISE VIVA® cannot degrade coumaric acid into coumaric acid which is the origin of volatile phenol precursors responsible for the development of the off-odors associated with *Brettanomyces bruxellensis*.



Efficiency of the bacteria confirmed in limiting conditions:

- low pH (3.2),
- high alcohol content (15% vol.),
- low temperature (15°C),
- initial acid malic concentration > 5 g/L,
- varieties known to be difficult for the MLF (Merlot/Tannat).

FML EXPERTISE VIVA® is a safe and fast bacteria.

	Riesling	Merlot	Cabernet S.	Tannat
Moment of inoculation	Co-inoculation	Post AF	Post AF	Post AF
pH	3.25	3.26	3.31	3.67
Malic acid	5.8 g/l	2 g/L	2.9 g/L	3.5 g/L
Ethanol	12.10%	12.3%	11.9%	14.9 %
SO ₂ total / Free SO ₂	15 / <5 mg/l	30 / <5 mg/l	39 / <5 mg/l	36 / 15 mg/L
Temperature	17°C, then 20°C	15°C	15°C	20°C


ORGANOLEPTIC IMPACT

- Do not produce biogenic amines.
- Very low and very late degradation of the citric acid at the end of the MLF, leading to a low production of volatile acidity as well as diacetyl (buttery and milky notes).
- Contribute to the freshness and the aromatic complexity of white, rose and red wines, respecting varietal aromas.



FML EXPERTISE VIVA® contributes to the freshness and the fruitiness of the wines.

A tasting has been organized with 39 international wine professionals. The wine inoculated with FML EXPERTISE VIVA® was rated with an excellent global appreciation, with more intensity of aromas in the nose (particularly fresh fruits) and a lot of freshness.



INSTRUCTIONS FOR USE

Direct inoculation (without rehydration) is possible:

- Open the sachet and add the FML EXPERTISE VIVA® without rehydration prior to or during a pumping-over:
 - directly into the fermenting must during a pumping-over (co-inoculation)
 - or directly into the wine after the end of alcoholic fermentation (AF) (post AF-fermentation)

For a best mixing, we recommend to:

- Add FML EXPERTISE VIVA® to 20 times its weight of clean chlorine-free water at 20°C.
- Stir. Rehydrate maximum 15 minutes.

Example: A 25 g sachet of FML EXPERTISE VIVA® for 25hL is rehydrated in 500 mL of water.

The instructions for use of this bacteria depend on the type of inoculation. 3 options:

Options 1 and 2 - Sequential inoculation in wine (end of alcoholic fermentation) or early inoculation (density 1020-1010):

- Add directly to the wine (using the pump-over method without aeration or homogenization with a nitrogen addition), or to the fermenting wine.
- Maintain wine temperature between 16°C and 18°C for white and rose wines, and between 18°C and 22°C for red wines.
- If the wine presents challenging (highly clarified wine, low pH, high SO₂ and alcohol levels, organic nitrogen deficiency, fermentation problems, etc.):
- Rehydrate bacteria with ATOUT MALO™ NATIVE (20 g/hL of wine to inoculate).
- Add ATOUT MALO™ BLANC for white wines or ATOUT MALO™ ROUGE for red wines (dose of 20 g/hL) before inoculating bacteria.

Option 3 - Co-inoculation of must (inoculation of bacteria 24 to 48 hours after the addition of yeast):

We recommend this method, which has become increasingly widespread due to its many benefits, during controlled alcoholic fermentation with no risk of a stuck fermentation (control over yeasting and nutritional requirements, an alcoholic strength by volume > 15%, temperature < 27°C, total SO₂ levels < 8 g/hL).

- The correct time to add the rehydrated bacteria to the must depends on the level of total SO₂:
 - 24 hours after yeasting if the level of SO₂ < 4 g/hL.
 - 48 hours after yeasting if the level of SO₂ is between 4 and 8 g/hL.
- Evaluate the MLF kinetics every 2 to 4 days.



↻ PACKAGING ↻

FML EXPERTISE VIVA® is available in quantities for 25 hL ou 100 hL.

↻ STORAGE & TRANSPORT ↻

18 months at 4°C.

36 months at -18°C.

Once opened, use rapidly.


Can withstand a few days at room temperature.

The quality of the FML EXPERTISE VIVA® is preserved if the product is stored at room temperature at a temperature below 25°C during 1 week. Similarly, their quality is not affected by temperature variations during transport provided that their frequency and intensity are limited:

Do not expose the product at a temperature above 30°C.

Limit the number of temperature peaks between 25 and 30°C.

A Danstar product, distributed by:



The information herein is true and accurate to the best of our knowledge; however, it is for reference purposes only, without warranty of any kind, either expressed or implied. Danstar cannot be held liable for any special, incidental, or consequential damages resulting from the purchase or use of this information.